

COMING UP ROSES



REMEMBER TO KEEP THE BACKING ON UNTIL YOU ARE READY TO RUB!!!

1. DECIDE WHERE YOU WANT TO PLACE YOUR MURAL.
2. FIND THE MIDDLE OF THE AREA AND PUT UP TWO OF THE FENCE PIECES NEXT TO ONE ANOTHER AT THAT POINT (MAKE SURE TO LEAVE ROOM FOR THE FLEUR DE LIST CONNECTORS BETWEEN EACH PIECE OF FENCE). THIS WILL ENSURE YOUR MURAL WILL BE CENTERED EXACTLY WHERE YOU WANT IT.
3. WORK OUTWARD WITH THE REMAINDER OF THE FENCE ON EACH SIDE OF THE FIRST TWO INITIAL PIECES.
4. APPLY THE CONNECTORS TO THE FENCE
5. IF YOU WOULD LIKE THE ARBOR, YOU WILL NEED TO PURCHASE AN ADDITIONAL WROUGHT IRON FENCE PACK. TAKE THE WROUGHT IRON FENCE SHEETS AND PLACE THEM ON TWO EXISTING FENCE PIECES. LEAVE TWO FENCES BETWEEN YOUR ARBOR (REFER TO PICTURE ABOVE); OR PLACE IT TO FIT YOUR AREA.
6. USE THE TRELIS ATTACHMENT AS A SAMPLE TO APPLY THE WROUGHT IRON SCROLL; OR DO IT AS YOU SEE FIT FOR YOUR AREA .
7. APPLY THE BOTTOM PORTION OF THE ROSE BUSH.
8. CAREFULLY PLACE THE BOTTOM EDGE OF THE TOP PORTION OF THE ROSE BUSH DOWN ON THE WALL EXACTLY LINING UP THE STEMS AND LEAVES FROM THE TOP AND BOTTOM THERE WILL BE SOME OVERLAY. DO THIS FOR BOTH ROSE BUSHES.
9. CUT YOUR ROSE VINE SHEETS WHERE INDICATED.
10. USE YOUR ROSE VINES TO MEANDER IN AND OUT OF THE ARBOR AND FENCE.
11. ACCENT WITH BIRDS AND BUTTERFLIES.
12. WE HAVE ALSO ADDED SOME ENGLISH IVY, VINES, AND YELLOW FLOWERS; WHICH CAN ALL BE PURCHASED SEPARATELY.