

TATOUAGE DESIGNS
PINE TREE - INSTRUCTIONAL INSERT

The completed Pine Tree will measure 50.5”w x 78.5”h. Before placing any Tatouage on the wall, make sure to measure your intended space. **Please remember to keep the protective backing on ALL sheets until they are ready to be applied to the wall.** (Please note in this instructional insert the Pine Tree is shown with our Field of Flowers behind it – sold separately)

1. Place sheet 1A Base up on the wall, using the “Level Line “ that is marked on the sheet make sure your sheet is level before removing protective backing and placing on wall.



2. Sheet 1B will go up next (see Fig. A) to the left of the trunk of the tree. Then Sheet 1C will go up to the right of the trunk of the tree (Fig. B)



Fig. A

Fig B

3. Sheet #2 Lower Middle (Fig C) will go up next. Followed by Sheet #3 (Fig. D) Lower Left and then Sheet #4 (Fig. E) Lower Right.



Fig C

Fig D

Fig E

4. Sheet #5 Middle (Fig F) will go up next. Followed by Sheet #6 Middle Left (Fig G) and then Sheet #7 (Fig H) Middle Right.



Fig F

Fig G

Fig H

5. Sheet #8 Top Left (Fig I) goes up next. Followed by Sheet #9 Top Right (Fig J)



Fig I

Fig J

6. Sheet #10 Outer Lower Left (Fig K) will be placed off the end of Sheet #3 Lower Left (See Step 3). Sheet #11 Outer Lower Right (Fig L) will be placed off the end of Sheet #4 Lower Right (See Step 3)



Fig K

Fig L