

**WINDOW SCENES INSTRUCTIONS
(NAPA VALLEY, MOUNTAIN, DESERTED ISLAND, LIGHTHOUSE)**



**Instructions and Helpful Hints for applying our Window Scenes
FIRST AND FOREMOST - PLEASE TAKE YOUR TIME!!!**

1. Lay out all designs on a clean surface. Make sure to keep all protective backings on! Tape them on if you need to.
2. Cut out individual pieces of the Arched Niche. Again, keep all protective sheets on the back.
3. On your wall, use a yardstick, level or measuring tape to mark off evenly where you want the inside of the Window Scene to go. Make sure to add the extra inches for the outside stone area (Arched Niche).
4. The first piece to be applied is the bottom of your Window Scene. Keeping the protective backing on, place on your wall. When you are happy with the positioning remove the protective backing out from behind and press down firmly from the inside out. Rub the entire design with the tongue depressor provided in the pack until the complete design has transferred to your wall.



5. Next line up the top piece of the Window Scene with the bottom. Again make sure the protective sheet is still on. Keep in mind that it is better to let the designs overlap a hair rather than see a gap where the design doesn't meet. When you are happy with the positioning, take the protective sheet out from behind and apply.



6. You are now ready to put the Arch Niche Stone on. Remember to keep all of the protective backing sheets on until you have finished laying out all of the Arch pieces. (DO NOT LET TAPE ADHERE TO ANY PIECES ALREADY APPLIED TO THE WALL)
7. Start with the bottom left piece. Again, let the niche piece slightly overlap the Window Scene by approximately 1/8" – 1/4" inch.



8. Now line up the bottom right corner of the niche, making sure that the middle crack lines up properly with the left side.



9. Next line up both the top left and top right sides of the Arch. Remember to keep the protective sheets on until you are happy with the placement.



10. Position the Keystone in the top of the Arch. When you are satisfied with placement remove the backing and apply to wall. Enjoy!!!

